




ISOKINETIC STEAM SAMPLE PROBES - ISP




DESCRIPTION


Isokinetic Steam Sampling Probes are used to obtain a representative sample from the saturated and superheated steam An appropriate analysis system starts with a correct sampling probe in process. If we do not take a representative sample process, we will never be able to have a reliable analysis system. This basic comment is sometimes undervalued in projects We can spend large amounts of money buying analyzers or conditioning systems, but if we don't have the right process sampling probe, probably we won't get the expected results.



V sample = V local Isokinetic sampling



V sample > V local Entrainment Undersampled



V sample < V local Entrainment Oversampled

The Isokinetic probes requires that the velocity of the fluid entering in the sample nozzle is exactly the same as the velocity of the streaming being sampled at the location of sample nozzle.

The bore of the nozzle and the size of the port shall be in accordance with calculated data (IECTR61831 or ASME D1066 and PTC19.11).

Each Isokinetic probe must be designed taking in account temperature, stresses, pressure, vibration, erosion, and strength of the attachment to the pipe.

MATERIALS

Usually these probes are manufactured in A182 316SS, however Manvia can manufacture these probes in other exotic materials. The process conditions must be considered.

For the design of this type of probes, it is necessary to have some data. Please fill the Annex of this document in case you require an offer.





ISOKINETIC STEAM SAMPLE ORDER FORM

Date		
Customer Information		-
Contact Name		
Company		
Street Address		
City		
County	Postco	ode
Phone Number		
Email Address		
Tag Number Probe		
Fluid to be sampled:		
Process Condition		
Maximum Flowrate in Process Pipe (during normal operation) (Kg/hr):		
Normal/Average Flowrate in Process Pipe (during normal operation) (Kg/hr):		
Operating Temperature (during normal operation) (°C):		
Operating Pressure (during normal operation) (barg):		





ISOKINETIC STEAM a member of JCT group SAMPLE ORDER FORM

Process Pipe

Process Pipe Material

Process Pipe OD (in):

Process Pipe design temperature (°C):

Process Pipe design Pressure (barg):

Process Pipe Wall (in) or Schedule:

Process Pipe Insulation Thickness (mm):

Isokinetic Probe data:


Process Connection:

Material

If Flanged: Indicate Size, type and Rating of flange:

If Flanged: indicate distance from process pipe OD to raised face of flange on process pipe (Nozzle length "M" mm.):

Note: "L" Insertion Length (mm): calculated by Manvia







ENVIRONMENTAL MONITORING& INDUSTRIAL MEASUREMENT SOLUTIONS



Headquarters

4E Street 6, An Phu Ward, Thu Duc City, Ho Chi Minh City

Hotline: (+84) 901 379 116



Ha Tinh Office

Lien Phu Hamlet, Ky Lien Ward, Ky Anh Town, Ha Tinh Province

Hotline: (+84) 938 442 414

Northern Viet An

Lot 33, BT4-1 residential area, Trung Van ward, Nam Tu Liem district, Hanoi

Hotline: (+84) 901 851 116



Eurowater Technology

9A Street 6, An Phu Ward, Thu Duc City, Ho Chi Minh City

Hotline: (+84) 909 788 959

Viet An Central

5A Mai Xuan Thuong Street, Hoa Khe Ward, Thanh Khe District, Da Nang City

Hotline: (+84) 898 119 116



iLotusLand Viet Nam

9A Street 6, An Phu Ward, Thu Duc City, Ho Chi Minh City

Hotline: (+84) 90 940 3778







